Column & Fire Equipment Guidelines			Booth 11732
Please be aware of building support columns with fire equipment in or around your booth space. General booth guidelines can be found here: https://www.namm.org/exhibit/thenammshow/important-guidelines/display-guidelines-rules-regulations NOTE: Fire equipment must be visable and accessible at all times			
	733 2 11832 F F S V E 6'-10'' 1	5'-6" 2'-4" 2'-2"	
REFERENCE GUIDELINES (unless otherise noted on map) <u>FS (Fire Strobe)</u> : Located at 20' height; Hall E are 12' height from the floor; ACC lobbies are 6'7" height from the floor. <u>FE (Fire Extinguisher)</u> : Must remain visible, accessible and unobstructed <u>SP (Fire Speaker)</u> : 6"x6" & located at 9'9" height from the floor and shall be visible and unobstructed <u>FHC (Fire Hose Connection)</u> : Must remain visible, accessible and unobstructed FDR (Facility Door Release): Must not be blocked		Building Support Column Exhibitors are free to brand & build around columns, as long as fire equipment is clear and nothing is adhered to the column or physical building.	
 measurements. This may vary slightly onsit All fire equipment on columns must remain v clear to the aisle. Fire alarm devices have a strobe and a spea 	isible and accessible at all times and fire hoses must be		



EVERY EFFORT HAS BEEN MADE TO ENSURE THE ACCURACY OF ALL INFORMATION CONTAINED ON THIS FLOORPLAN. HOWEVER, NO WARRANTIES, EITHER EXPRESSED OF IMPLIED, ARE MADE WITH RESPECT TO THIS FLOORPLAN. IF THE LOCATION OF BUILDING COLUMNS, UTILITIES OR OTHER ARCHITECTURAL COMPONENTS OF THE FACILITY IS A CONSIDERATION IN THE CONSTRUCTION OR USAGE OF AN EXHIBIT, IT IS THE SOLE RESPONSIBILITY OF THE EXHIBITOR TO PHYSICALLY INSPECT THE FACILITY TO VERIFY ALL DIMENSION AND LOCATIONS. ©COPYRIGHT 2007, FREEMAN, ALL RIGHTS RESERVED.