Column & Fire Equipment Guidelines				Booth 1916	
Please be aware of building support col General booth guidelines can be found https://www.namm.org/exhibit/thenamm NOTE: Fire equipment must be visable	here: show/important-guidelines/display-g				
2'	1918 		20'		
18'	20'	20	17		
	1916	20	16		
REFERENCE GUIDELINES (unless otherise not	ted on map)				
<u>FS (Fire Strobe)</u> : Located at 20' height; Hall E are 12' height from the floor; ACC lobbies are 6'7" height from the floor. <u>FE (Fire Extinguisher)</u> : Must remain visible, accessible and unobstructed <u>SP (Fire Speaker)</u> : 6"x6" & located at 9'9" height from the floor and shall be visible and unobstructed <u>FHC (Fire Hose Connection)</u> : Must remain visible, accessible and unobstructed FDR (Facility Door Release): Must not be blocked			Building Support Column Exhibitors are free to brand & build around columns, as long as fire equipment is clear and nothing is adhered to the column or physical building.		
 PLEASE NOTE: This diagram indicates the size and approxime measurements. This may vary slightly onsi All fire equipment on columns must remain variable clear to the aisle. Fire alarm devices have a strobe and a speateness may not be affixed to columns; dare Convention Center. 	te once the floor has been marked visible and accessible at all times and fire aker at two different heights on a column	hoses must be			

FREEMAN	F	R	Ε	E	Μ	Α	N
---------	---	---	---	---	---	---	---

EVERY EFFORT HAS BEEN MADE TO ENSURE THE ACCURACY OF ALL INFORMATION CONTAINED ON THIS FLOORPLAN. HOWEVER, NO WARRANTIES, EITHER EXPRESSED OF IMPLIED, ARE MADE WITH RESPECT TO THIS FLOORPLAN. IF THE LOCATION OF BUILDING COLUMNS, UTILITIES OR OTHER ARCHITECTURAL COMPONENTS OF THE FACILITY IS A CONSIDERATION IN THE CONSTRUCTION OR USAGE OF AN EXHIBIT, IT IS THE SOLE RESPONSIBILITY OF THE EXHIBITOR TO PHYSICALLY INSPECT THE FACILITY TO VERIFY ALL DIMENSION AND LOCATIONS. ©COPYRIGHT 2007, FREEMAN, ALL RIGHTS RESERVED.