Column & Fire Equipment Guidelines	Booth 2339
Please be aware of building support columns with fire equipment in or around your booth space. General booth guidelines can be found here: https://www.namm.org/exhibit/thenammshow/important-guidelines/display-guidelines-rules-regulations NOTE: Fire equipment must be visable and accessible at all times	
EP Keep Clear FS FS FS FS FS SP 1'-1 SP 1'-1 SP 1'-1 (LPE 3'-2'-5" (SP 1'-1) (Clear) SP 1'-1 (SP 1'-2" (SP 1'-2") (SP 1'-1") (SP 1'-2") (SP (SP 1') (SP (SP (SP (SP (SP (SP)) (SP (SP) (SP)	
2339 20'	
Image: Strobel. Located at 20 height, har 2 are 12 height from the floor, Acc hobbles are 6'7" height from the floor. Exhibitors are FE (Fire Extinguisher): Must remain visible, accessible and unobstructed SP (Fire Speaker): 6"x6" & located at 0'0" height from the floor and shall be visible.	ng Support Column free to brand & build around ong as fire equipment is clear adhered to the column or ng.
 PLEASE NOTE: This diagram indicates the size and approximate position of the obstruction within the booth with measurements. This may vary slightly onsite once the floor has been marked All fire equipment on columns must remain visible and accessible at all times and fire hoses must be clear to the aisle. Fire alarm devices have a strobe and a speaker at two different heights on a column Materials may not be affixed to columns; damage will be billed back to the exhibitor by the Anaheim Convention Center. 	

1



EVERY EFFORT HAS BEEN MADE TO ENSURE THE ACCURACY OF ALL INFORMATION CONTAINED ON THIS FLOORPLAN. HOWEVER, NO WARRANTIES, EITHER EXPRESSED OF IMPLIED, ARE MADE WITH RESPECT TO THIS FLOORPLAN. IF THE LOCATION OF BUILDING COLUMNS, UTILITIES OR OTHER ARCHITECTURAL COMPONENTS OF THE FACILITY IS A CONSIDERATION IN THE CONSTRUCTION OR USAGE OF AN EXHIBIT, IT IS THE SOLE RESPONSIBILITY OF THE EXHIBITOR TO PHYSICALLY INSPECT THE FACILITY TO VERIFY ALL DIMENSION AND LOCATIONS. ©COPYRIGHT 2007, FREEMAN, ALL RIGHTS RESERVED.