Column & Fire Equipment Guidelines	Booth 2349
Please be aware of building support columns with fire equipment in or around your booth space. General booth guidelines can be found here: https://www.namm.org/exhibit/thenammshow/important-guidelines/display-guidelines-rules-regulations NOTE: Fire equipment must be visable and accessible at all times	
8' <b>20'</b>	
	0'
2349	
are 6'7" height from the floor. <u>FE (Fire Extinguisher)</u> : Must remain visible, accessible and unobstructed <u>SD (Fire Strongers)</u> : Must remain visible, accessible and unobstructed <u>Columns</u> ,	suilding Support Column s are free to brand & build around , as long as fire equipment is clear ing is adhered to the column or building.
<ul> <li>PLEASE NOTE:</li> <li>This diagram indicates the size and approximate position of the obstruction within the booth with measurements. This may vary slightly onsite once the floor has been marked</li> <li>All fire equipment on columns must remain visible and accessible at all times and fire hoses must be clear to the aisle.</li> <li>Fire alarm devices have a strobe and a speaker at two different heights on a column</li> <li>Materials may not be affixed to columns; damage will be billed back to the exhibitor by the Anaheim Convention Center.</li> </ul>	

FREEMAN

EVERY EFFORT HAS BEEN MADE TO ENSURE THE ACCURACY OF ALL INFORMATION CONTAINED ON THIS FLOORPLAN. HOWEVER, NO WARRANTIES, EITHER EXPRESSED OF IMPLIED, ARE MADE WITH RESPECT TO THIS FLOORPLAN. IF THE LOCATION OF BUILDING COLUMNS, UTILITIES OR OTHER ARCHITECTURAL COMPONENTS OF THE FACILITY IS A CONSIDERATION IN THE CONSTRUCTION OR USAGE OF AN EXHIBIT, IT IS THE SOLE RESPONSIBILITY OF THE EXHIBITOR TO PHYSICALLY INSPECT THE FACILITY TO VERIFY ALL DIMENSION AND LOCATIONS. ©COPYRIGHT 2007, FREEMAN, ALL RIGHTS RESERVED.