Column & Fire Equipmen	Booth 7447	
General booth guideline https://www.namm.org/	ding support columns with fire equipment in or around your booth spaces can be found here: exhibit/thenammshow/important-guidelines/display-guidelines-rules-re must be visable and accessible at all times	
	7447 20'	
	20'	15'-7"
	FS FS FS SCR/W SP E	2'-6"
REFERENCE GUIDELINES (unless otherise noted on map) <u>FS (Fire Strobe)</u> : Located at 20' height; Hall E are 12' height from the floor; ACC lobbies are 6'7" height from the floor. <u>FE (Fire Extinguisher)</u> : Must remain visible, accessible and unobstructed <u>SP (Fire Speaker)</u> : 6"x6" & located at 9'9" height from the floor and shall be visible and unobstructed <u>FHC (Fire Hose Connection)</u> : Must remain visible, accessible and unobstructed FDR (Facility Door Release): Must not be blocked		Building Support Column Exhibitors are free to brand & build around columns, as long as fire equipment is clear and nothing is adhered to the column or physical building.
<ul> <li>PLEASE NOTE:</li> <li>This diagram indicates the measurements. This ma</li> <li>All fire equipment on colu clear to the aisle.</li> <li>Fire alarm devices have a</li> <li>Materials may not be affix Convention Center.</li> </ul>	e size and approximate position of the obstruction within the booth with y vary slightly onsite once the floor has been marked mns must remain visible and accessible at all times and fire hoses must be strobe and a speaker at two different heights on a column ed to columns; damage will be billed back to the exhibitor by the Anaheim	
FREEMAN	EVERY EFFORT HAS BEEN MADE TO ENSURE THE ACCURACY OF ALL INFORMATION CONTAINED ON THIS FLOORPLAN. FLOORPLAN. IF THE LOCATION OF BUILDING COLUMNS, UTILITIES OR OTHER ARCHITECTURAL COMPONENTS OF THE RESPONSIBILITY OF THE EVALUTION EVALUTION FOR STATUS AND A STATUS AN	ACILITY IS A CONSIDERATION IN THE CONSTRUCTION OR USAGE OF AN EXHIBIT, IT IS THE SOLE